

7350 init 1 and 2 procedure

eprom initialization

1. Load at least 2 sheets of full-width, continuous pin-feed forms
In the rear tractors. (printer still powered off)
2. Plug in power cord.
3. Move form lever (above power switch) to R pin feed selection
(second position from top)
4. Hold down HIGH IMPACT& LF buttons and power on.
5. Continue holding until display reads "EPROM INITIAL 1"
6. When initialization 1 is complete the printer will enter a ready
state and the print head will stop.
7. Power off.
8. Now hold SPEED & TEAR OFF buttons and power on.
9. Release when " EPROM INITIAL 2" is displayed.
10. Press ENTER when the display prompts you. The forms will
load and sensor tests will be performed.
11. When "CHECK OVER" is displayed, press HIGH IMPACT and
printer will enter a ready state.

END OF PROCEDURE