

### **M7 media calibration**

You will need to calibrate the printer for use with gap media (labels). There are 2 ways you can do a calibration –

1. Use the diagtool utility to calibrate the printer (see user guide) download here <http://www.amtdatasouth.com/support-1/downloads/manuals/>  
-or-
2. Use the printer panel to calibrate –

For printer panel calibration:

1. Load the labels and make sure the sensor is positioned over the labels (not off the edge where it won't see them)
2. With the printer Ready, press the MENU button
3. Press SELECT button
4. Press DOWN once (Sensor is highlighted)
5. Press SELECT
6. Press DOWN to (Calibration)
7. SELECT
8. (Gap Mode) press SELECT
9. (Automatic) press SELECT
10. It will feed 2 or 3 labels and should stop on at the tear off position
11. Turn printer off, wait at least 5 seconds, then turn back on.
12. Press FEED a few times to verify it feeds one label per button press.

Now try your job.