

## ANTI-STATIC SUPPRESSION KIT INSTALLATION INSTRUCTIONS

(For the XL 300 and XL 400 printers)

Part No. BBF-105953 Rev.\*


### Bill of Materials

Item No.	Part No.	Description	Quantity
1	BAV-105255	tinsel retainers	2
2	AAB-105257	tinsel assembly	1
3	BAN-102860	screw, mach-phil, #10-32 x 1"	2

Note: The static kit must be installed by a qualified technician.

### Installing the Static Kit

The #10-32 x 1" screws are intended for use in the locations shown below.




**1. Place the front edge of the printer over the table edge.**

**2. Secure a tinsel retainer to the bottom of the printer by installing the screw through the bottom of the printer. Orient the tinsel retainer as shown. The screw should protrude through the right endplate.**

**3. Repeat this procedure for the left side of the printer.**



**4. Install the tinsel and spring assembly. Make certain the spring is located as shown.**



**5. Make certain the tinsel will touch both sides of the paper when paper is loaded into the printer.**